


# LUXEON FX2-L CW

## Optical Rayset Readme


July 23rd, 2020




# LUXEON FX2-L CW

## Coordinate system

Top view



Side view




**CAD file and rayset files share the same coordinate system,  
the origin is marked by the red dot in the sketches above:**

xy center == center of light emitting area  
z=0 plane == top edge of light emitting area

# LUXEON FX2-L CW

## Source size




The two orthogonal lines in the luminance image mark the reference planes of the two luminance cross sections.

# LUXEON FX2-L CW

## Luminous intensity distribution

Intensity per lumen over angle for vertical and horizontal slices  
with lambertian cosine as reference



# Download File Nomenclature (see next slide)

## Example

LUXEON\_Altilon\_SMD2\_1x4\_gen4plus\_20190206\_20Mray\_proj\_Z\_spectral\_LT.ray

**Product Name**

**Reference Date**

helps identifying underlying dataset

**Number of rays**

e.g. 20 M =  $20 \cdot 10^6$  rays

**Ray starting points**

'proj' indicates that ray starting points have been **projected** onto the CAD surface (---).

**Spectral range**

$\begin{Bmatrix} Y \\ Z \\ - \end{Bmatrix} = \begin{Bmatrix} \text{only yellow} \\ \text{only blue} \\ \text{full} \end{Bmatrix}$  spectrum taken into account



**Spectral Information**

$\begin{Bmatrix} \text{spectral} \\ - \end{Bmatrix} = \text{individual rays } \begin{Bmatrix} \text{do} \\ \text{don't} \end{Bmatrix} \text{ carry wavelength information}$

**Target Software Package**

LightTools (LT), ASAP, Zemax, ...

**File Extension**



## Additional Application Notes

### Randomization

In some cases, reducing the number of rays in a rayset might be desirable. In order to facilitate the generation of reduced raysets, **all raysets mentioned in this readme file are randomized**. Hence, a rayset having 5 million rays (5M) can simply be generated by taking the first 5M rays from 20M rayset.


### Projected Raysets: Propagated ray starting points

For projected raysets, the following procedure is applied for obtaining the starting points:

- (1) Project rays on CAD surface (---) → ray starting points
- (2) Propagate rays by 0.5  $\mu\text{m}$  → propagated starting points (•)

**All raysets mentioned in this readme file provide propagated starting points.**

If raytracing includes the LED CAD, unpropagated rays are prone to be blocked at the surface. Rays with propagated starting points should not suffer from this problem.



# LUXEON FX2-L CW

Link to download folder

<https://raysets.lumileds.com/index.php/s/NqLwaKb6tibQxM9>

## Files available for download

### Prosource

RS8	LUXEON_FX2_L_CW_20200723_20MRays_1316.rs8	641 MB
-----	---	--------

### LightTools

Spectral Projected	LUXEON_FX2_L_CW_20200723_40MRays_proj_spectral_LT.ray	1.19 GB	40MRays
Y-Component Projected	LUXEON_FX2_L_CW_20200723_20MRays_proj_Y_LT.ray	533 MB	20MRays
Z-Component Projected	LUXEON_FX2_L_CW_20200723_20MRays_proj_Z_LT.ray	531 MB	20MRays

### ASAP & LucidShape

Y-Component Projected	LUXEON_FX2_L_CW_20200723_20MRays_proj_Y_ASAP.dis	533 MB	20MRays
Z-Component Projected	LUXEON_FX2_L_CW_20200723_20MRays_proj_Z_ASAP.dis	531 MB	20MRays

### OPTIS SPEOS

Y-Component Spectral Projected	LUXEON_FX2_L_CW_20200723_20MRays_proj_Y_spectral_Speos.ray	609 MB	20MRays
Z-Component Spectral Projected	LUXEON_FX2_L_CW_20200723_20MRays_proj_Z_spectral_Speos.ray	607 MB	20MRays

### Zemax

Spectral Projected	LUXEON_FX2_L_CW_20200723_40MRays_proj_spectral_zemax.dat	1.19 GB	40MRays
--------------------	--	---------	---------

### Far Field

IES	LUXEON_FX2_L_CW_20200723_40MRays.ies	10.6 kB
-----	--------------------------------------	---------

### Spectrum


Spectrum	LUXEON_FX2_L_CW_20200723_spectrum.txt	17.4 kB
----------	---------------------------------------	---------

### CAD

STEP	LUXEON_FX2_L_CW_20200723_geometry.STEP	102 kB
IGES	LUXEON_FX2_L_CW_20200723_geometry.IGS	77.4 kB

# LUXEON FX2-L CW


3D CAD view + ray starting points






# LUXEON FX2-L CW

## Illuminance color chart (color over position)



# LUXEON FX2-L CW

Measured spectrum split in blue (Z) and yellow (Y) components



## LUXEON FX2-L CW

### Color data info

Parameter	Value
yellow : blue ratio (W) (from measured spectrum)	0.6769 : 0.3231
yellow : blue ratio (lm) (from measured spectrum)	0.987 : 0.01297
Average color point Cx, Cy (from measured spectrum)	0.3256, 0.3353
Average color point Cx, Cy (from simulation)	0.3254, 0.3371
Color point Cx, Cy @ HV (from simulation)	0.3176, 0.3206
Average CCT (K) (from simulation)	5.824e+03

Lumileds ref.: 1316\_LUXEON FX2-L CW\_20200723



Neither Lumileds Holding B.V. nor its affiliates shall be liable for any kind of loss of data or any other damages, direct, indirect or consequential, resulting from the use of the provided information and data. Although Lumileds Holding B.V. and/or its affiliates have attempted to provide the most accurate information and data, the materials and services information and data are provided “as is,” and neither Lumileds Holding B.V. nor its affiliates warrants or guarantees the contents and correctness of the provided information and data. Lumileds Holding B.V. and its affiliates reserve the right to make changes without notice. You as user agree to this disclaimer and user agreement with the use of the provided materials, information and data. A listing of Lumileds product/patent coverage may be accessed at [lumileds.com/patents](https://lumileds.com/patents).